

SN

Approach Lighting System

FTS 800A

Equipment Reference Manual

Front Matter

Abstract

This manual describes the *Installation, Maintenance, and Operation* of the FTS 800A Approach Lighting System (ALS).

Copyright

Copyright © 1997-2001 Flash Technology Corporation of America[®], Franklin, TN 37067, U.S.A. All rights reserved. Reproduction or use of any portion of this manual is prohibited without express written permission from Flash Technology Corporation of America and/or its licensor.

Trademark Acknowledgments

Flash Technology Corporation of America[®] is a registered trademark name. ElectroFlash[™], Flash Tech[™], Flash Technology[™], FTCA[™], Flash[™], and the Flash Technology Logo are all trademarks of Flash Technology Corporation of America[®].

All trademarks and product names mentioned are properties of their respective companies, and are recognized and acknowledged as such by Flash Technology Corporation of America.

Applicable Specification

This equipment meets or exceeds requirements for an FAA Type L-849 Style A and E light in Advisory Circular 150/5345-51.

Disclaimer

While every effort has been made to ensure that the information in this manual is complete, accurate and up-to-date, Flash Technology Corporation of America assumes no liability for damages resulting from any errors or omissions in this manual, or from the use of the information contained herein. Flash Technology Corporation of America reserves the right to revise this manual without obligation to notify any person or organization of the revision.

In no event will Flash Technology Corporation of America be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of or the inability to use this manual.

Warranty

Flash Technology Corporation of America warrants all components, under normal operating conditions, for two years.

Parts Replacement

The use of parts not supplied by FTCA or unauthorized modification of this equipment voids the warranty and could invalidate the assurance of complying with FAA requirements.

Pub. No. 0594-800A-0007

PERSONNEL HAZARD WARNING

Dangerous Voltages

Dangerous line voltages reside in certain locations in this equipment. Also, this equipment may generate dangerous voltages. Although FTCA has incorporated every practical safety precaution, exercise extreme caution at all times when you expose circuits and components, and when you operate, maintain, or service this equipment.

Avoid Touching Live Circuits

Avoid touching any component or any part of the circuitry while the equipment is operating. Do not change components or make adjustments inside the equipment with power on.

Dangerous Voltages Can Persist with Power Disconnected

Under certain conditions, dangerous voltages can be present because capacitors can retain charges even after the power has been disconnected. Protect yourself—always turn off the input (primary) power and wait for one minute for storage capacitors to drain their charge. Then check between the red and blue wires on the TB2 terminal block with a voltmeter for any residual charge before touching any circuit element or component.

Do Not Depend on Interlocks

Never depend on interlocks alone to remove unsafe voltages. Always check circuits with a voltmeter. Under no circumstances remove or alter any safety interlock switch.

Table of Contents

Section	Page
Front Matter	ii
Abstract	ii
Copyright	ii
Trademark Acknowledgments	ii
Applicable Specification	ii
Disclaimer	ii
Warranty	ii
Parts Replacement	ii
Table of Contents	iv
List of Figures	v
List of Tables	v
 Section 1 — Introduction and Operation	 1-1
System	1-1
System Components	1-1
Specifications	1-1
Options and Variations	1-1
Operation	1-2
Lighting Unit Operation	1-2
Lighting Unit Intensity	1-2
Setup of the PC 800-3A Light	1-2
Cutable Jumpers	1-2
60/50 Hz Operation	1-2
Programming for Lighting Unit Position	1-2
Indicator Lamps	1-3
 Section 2 — Outline, Mounting, and Installation	 2-1
Unpacking	2-1
Tools	2-1
Access	2-1
System Configurations	2-1
Mounting	2-1
Wiring	2-2
Installation Checklist	2-2
 Section 3 — Maintenance and Troubleshooting	 3-1
Preventive Maintenance	3-1
Storage	3-1
RFI Problems	3-1
Operation Checkout	3-1
Mode Control for Manual	
Operation	3-1
Troubleshooting	3-2
Component Testing	3-3
Inspection	3-3
Power Converter	3-3
Capacitors (C1, C2, C3)	3-3
Relays (K1, K2)	3-4

Table of Contents (cont'd)

Section	Page
High Voltage Rectifier Board (PCB2)	3-4
High Voltage Transformer (T1)	3-4
Trigger Coupling Transformer (T3)	3-4
Timing and Trigger Board (PCB1)	3-4
Bleed Resistor (R1)	3-4
Interlock Switch (S1)	3-4
Flashhead	3-4
Flashtube (FT101)	3-4
Component Removal and Replacement	3-4
High Voltage Transformer (T1)	3-5
Trigger Coupling Transformer (T3)	3-5
Timing and Trigger Board (PCB1)	3-5
HV Rectifier Board (PCB2)	3-5
Energy Storage Capacitors	3-5
Section 4 — Replaceable and Spare Parts	4-1
Customer Service	4-1
Ordering Parts	4-1
Power Converter Parts and Spare Parts	4-1
Flashhead Parts	4-1
Returning Equipment	4-1
Repackaging	4-1
Index	I-1

List of Figures

Figure	Page
1-1 PCB1 Timing and Trigger Board Pictorial	1-4
2-1 Recommended External Power Switching	2-3
2-2 Installation Wiring of an FTS 800A System with Four Lighting Units	2-4
2-3 Comounted Lighting Unit — Mounting and Outline	2-5
2-4 Flashhead Mounting and Outline	2-6
2-5 Flashhead Internal Wiring	2-7
2-6 Power Converter Internal Wiring	2-8
4-1 Power Converter Component Locations	4-3
4-2 Flashhead Component Locations	4-4

List of Tables

Table	Page
1-1 PCB1 Board LEDs and Lamps	1-3
1-2 PCB1 Timing and Trigger Sequence Jumper Positions	1-5
1-3 PCB1 Timing and Trigger Address Jumper Positions	1-6
3-1 Mode Control	3-2
3-2 Observed Behavior	3-2
3-3 Defective Component Locator Code from Table 3-2	3-3
3-4 T1 Transformer Voltages	3-4
4-1 Power Converter Major Replaceable Parts	4-2

Table of Contents (cont'd)

Table.....	Page
4-2 Flashhead Replaceable Parts	4-4

Section 1 — Introduction and Operation

System

FTS 800A Lighting Systems are white, flashing, unidirectional systems for runway approach lighting applications. These systems meet or exceed requirements of Federal Aviation Administration (FAA) Advisory Circular 150/5345-51 for Type L-849 Style A, C, and E Lighting Units for three-intensity, white, sequential flashing lights for use in approach lighting systems (ALS). In ALS applications, the lights are aligned with the center line of the runway and flash sequentially toward the landing threshold.

System Components

An FTS 800A System consists of two or more Lighting Units and an FTC 183 System Controller. A flashhead and a power converter comprise each Lighting Unit. The flashhead and power converter may be comounted on the same pedestal, or separately mounted.

The flashhead consists of a sealed-beam flashlamp in a protective housing. The flashhead uses a xenon flashtube. Each light beam covers a minimum of 10 degrees vertically and 30 degrees horizontally.

The power converter is a separate cabinet containing the circuitry necessary to convert main input power to the voltages needed to operate the flashhead and other internal circuits. It contains the PCB1 Timing and Trigger Board, which controls the operation of the flashhead.

The external FTC 183 Controller is housed in its own separate enclosure. You can locate the Controller any practical distance from the rest of the system. The controller interfaces with the power converters. Systems with more than 25 lights in a 50 Hz system, or more than 28 lights in a 60 Hz system require a second controller.

Specifications

Physical:

Power Converter (H x W x D):	12.25 x 20.00 x 14.00; 21 lbs. 311.15 x 508.00 x 355.60; 9.53 kg.
Comounted Assembly (H x W x D)	24.50 x 25 x 14.00 in., 25 lbs. 622.30 x 635 x 355.60 mm, 11.34 kg.
Flashhead (H x W x D)	8.90 x 6 in., 4 lbs. 226.06 x 152 mm, 1.82 kg.

Heights include dimensions of the units only and do not include the distance from the bottom of each unit to the ground.

Performance Characteristics:

Application	L-849
Power Requirements:	
Voltage and Frequency (factory set):	120, 240, 480 VAC, 60 Hz 230 VAC, 50 Hz
Volt-Amperes	200 VA peak
Power at 120 fpm	175 Watts high intensity 65 Watts medium intensity 30 Watts low intensity
Power at 60 fpm	100 Watts high intensity 45 Watts medium intensity 25 Watts low intensity
Flash Intensity — Three levels:	
High Intensity	15,000 ±25% ECD
Medium Intensity	1,500 ±25% ECD
Low Intensity	300 ±25% ECD
Flash Rate	120 flashes per minute
Flash Coverage:	
Horizontal	30 degrees (minimum)
Vertical	10 degrees (minimum)
Control Interface:	FTC 183 external controller
Monitoring and Environmental:	FAA Advisory Circular AC 150/5345-51 compliance

Options and Variations

Call Customer Service at 1-800-821-5828 for options and variations.

Operation

The center of operations of each power converter is the Timing and Trigger Board (PCB1). PCB1 has the following programming features:

- Internal programming by the factory
- Cutable jumpers JP1 to JP12, JP14, and JP15 or dipswitches S1 to S3

Upon your order, the factory sets up the desired operation by cuttable jumpers or dipswitches and internal programming. However, you can change some operations in the field by using the information in the *Figure 1-1*. Otherwise, the operation is automatic. The indicator lights shown are useful for monitoring the equipment's operation.

Lighting Unit Operation

The controller connects to the power converters in the Lighting Units. See *Figure 2-2*. See the FTC 183 Controller Manual for more information.

The controller distributes a flash signal to all units in a system. Each Power Converter has internal circuitry to fix the instant at which it flashes. The interval is based on the position of the light in the sequential system. The flash signal from the controller also contains flash intensity information.

The monitor lines transmit a signal back to the System Controller indicating to the controller that the Lighting Unit has either flashed or not flashed its light, allowing the controller to indicate the result on the front panel.

Except for Lighting Unit intensity, the remaining operation is entirely automatic. Once the system is properly wired, it begins to operate when power is applied.

Lighting Unit Intensity

The intensity levels of the Lighting Units depends on the switch setting of the System Controller. To manually change the intensity of the lights, you must change the settings on the manual intensity switch, labeled CONTROL, on the System Controller: **L** is the low intensity

setting; **M** is the medium intensity setting; **H** is the high intensity setting; **FLASH INHIBIT** turns off the strobes, *but the units are still powered*; and **REMOTE** allows control of system intensity by a remote device.

Setup of the PC 800-3A Light

Cutable Jumpers

60/50 Hz Operation

The PCB1 can operate from either a 60 Hz or a 50 Hz power source. *The factory cuts jumper JP15 on PCB1 or turns off switch S1-4 when your installation is supplied by 50 Hz power.*

PERSONNEL HAZARD WARNING

Read the warning on Page iii.

When replacing the PCB1, the jumpers or dipswitch on the replacement board must be configured to exactly match the original board. A dipswitch in the open or off position is the same as a cut jumper.

Programming for Lighting Unit Position

Two sets of jumpers or dipswitches reside on PCB1. The first set, jumpers JP1 to JP7 or dipswitch S3 determine where the light will flash in the sequential system. Position one (1) flashes first then position two (2) flashes next and so on. *For example, if the system had three (3) lights and Light A had no jumpers cut or switches open and Light B had jumper JP1 cut or S3-1 open and Light C had jumper JP2 cut or S3-2 open, then the lights would flash in sequence A-B-C.* In a 50 Hz system there are 50 programmable positions and in a 60 Hz system there are 60. Note however, that a 50 Hz system controller will only monitor 25 lights and a 60 Hz system controller will only monitor 28 lights. If more lights are needed, use a second, synchronized, controller and separate monitor line. Table 1-2 shows which jumpers to cut for each position of the lights in the sequential system. This table also works for dipswitch S3; a dipswitch in the open or off position is the same as a cut jumper. Refer to *Figure 1-1* for jumper/dipswitch locations, labeled with the heading **FLASH**.

The second set of jumpers, JP8 to JP12 or dipswitch S2 and S1-1 program where the light sends its flash confirm signal to the system controller monitoring the lights. This monitor address should be set to the same value as the flash sequence position. For example, if the flash sequence position of the light were set to 5 by cutting JP3 or setting dipswitch S3-3 to off, then the monitor address should also be set to 5 by cutting JP10 or setting S2-3 to off. However, it is not required that the monitor address be exactly the same as the flash sequence position. It is only required that each light have a unique monitor address. Lights that flash simultaneously, (REIL A, B) must be assigned a separate monitor address. For example, REIL lights A and B both flash at sequence position 5, A should be assigned monitor address 5 while B would be assigned monitor address 6. Usually REIL lights are assigned the last flash sequence position in the system. Table 1-3 shows which jumpers to cut for each address of

the light in the sequence. This table also works for dipswitch S2 and S1-1; a dipswitch in the open or off position is the same as a cut jumper. Refer to *Figure 1-1* for jumper/dipswitch locations, labeled with the heading **CONFIRM**.

NOTE: The units come factory configured for flash sequence position and monitor address.

Indicator Lamps

Eight indicator LEDs and one neon lamp on PCB1 monitor equipment operation. A name imprinted on PCB1 adjacent to the lamp or LED identifies it. *Figure 1-1* shows the location of these indicators on the board.

Table 1-1 PCB1 Board LEDs and Lamps

LED/Lamp	Name	Color	Indication
SYNC	I 1	Red	A valid sync signal was received on the CONTROL terminal (PIn 6).
CONF	I 2	Red	A flash confirmation signal is present on the MONITOR terminal (Pin 5).
DAY	I 3	Red	DAY mode operation (high intensity) is active.
TWI	I 4	Red	TWILIGHT mode operation (medium intensity) is active.
NITE	I 5	Red	NITE mode (low intensity) operation is active.
TEST	I 6	Red	A self-test is in progress.
CAUT	I 7	Red	Flashes: PCB1 is in manual operation (see <i>Section Mode Control for Manual Operation</i> on Page 3-1).
PHASE	I 8	Red	Flashes: CONTROL input signal did not return to zero after receiving a valid sync signal.
NEON Lamp	I 9	Clear	120 VAC trigger voltage. This lamp may flicker.




Figure 1-1 PCB1 Timing and Trigger Board Pictorial

Table 1-2 PCB1 Timing and Trigger Sequence Jumper Positions

				Jumper, DipSW			
Flash Sequence	JP1, S3-1	JP2, S3-2	JP3, S3-3	JP4, S3-4	JP5, S3-5	JP6, S3-6	JP7, S3-7
1							
2	CUT. OFF						
3		CUT. OFF					
4	CUT. OFF	CUT. OFF					
5			CUT. OFF				
6	CUT. OFF		CUT. OFF				
7		CUT. OFF	CUT. OFF				
8	CUT. OFF	CUT. OFF	CUT. OFF				
9				CUT. OFF			
10	CUT. OFF			CUT. OFF			
11		CUT. OFF		CUT. OFF			
12	CUT. OFF	CUT. OFF		CUT. OFF			
13			CUT. OFF	CUT. OFF			
14	CUT. OFF		CUT. OFF	CUT. OFF			
15		CUT. OFF	CUT. OFF	CUT. OFF			
16	CUT. OFF	CUT. OFF	CUT. OFF	CUT. OFF			
17					CUT. OFF		
18	CUT. OFF				CUT. OFF		
19		CUT. OFF			CUT. OFF		
20	CUT. OFF	CUT. OFF			CUT. OFF		
21			CUT. OFF		CUT. OFF		
22	CUT. OFF		CUT. OFF		CUT. OFF		
23		CUT. OFF	CUT. OFF		CUT. OFF		
24	CUT. OFF	CUT. OFF	CUT. OFF		CUT. OFF		
25				CUT. OFF	CUT. OFF		
26	CUT. OFF			CUT. OFF	CUT. OFF		
27		CUT. OFF		CUT. OFF	CUT. OFF		
28	CUT. OFF	CUT. OFF		CUT. OFF	CUT. OFF		
29			CUT. OFF	CUT. OFF	CUT. OFF		
30	CUT. OFF		CUT. OFF	CUT. OFF	CUT. OFF		
31		CUT. OFF	CUT. OFF	CUT. OFF	CUT. OFF		
32	CUT. OFF	CUT. OFF	CUT. OFF	CUT. OFF	CUT. OFF		
33						CUT. OFF	
34	CUT. OFF					CUT. OFF	
35		CUT. OFF				CUT. OFF	
36	CUT. OFF	CUT. OFF				CUT. OFF	
37			CUT. OFF			CUT. OFF	
38	CUT. OFF		CUT. OFF			CUT. OFF	
39		CUT. OFF	CUT. OFF			CUT. OFF	
40	CUT. OFF	CUT. OFF	CUT. OFF			CUT. OFF	
41				CUT. OFF		CUT. OFF	
42	CUT. OFF			CUT. OFF		CUT. OFF	
43		CUT. OFF		CUT. OFF		CUT. OFF	
44	CUT. OFF	CUT. OFF		CUT. OFF		CUT. OFF	
45			CUT. OFF	CUT. OFF		CUT. OFF	
46	CUT. OFF		CUT. OFF	CUT. OFF		CUT. OFF	
47		CUT. OFF	CUT. OFF	CUT. OFF		CUT. OFF	
48	CUT. OFF	CUT. OFF	CUT. OFF	CUT. OFF		CUT. OFF	
49					CUT. OFF	CUT. OFF	
50	CUT. OFF				CUT. OFF	CUT. OFF	
51		CUT. OFF			CUT. OFF	CUT. OFF	
52	CUT. OFF	CUT. OFF			CUT. OFF	CUT. OFF	
53			CUT. OFF		CUT. OFF	CUT. OFF	
54	CUT. OFF		CUT. OFF		CUT. OFF	CUT. OFF	
55		CUT. OFF	CUT. OFF		CUT. OFF	CUT. OFF	
56	CUT. OFF	CUT. OFF	CUT. OFF		CUT. OFF	CUT. OFF	
57				CUT. OFF	CUT. OFF	CUT. OFF	
58	CUT. OFF			CUT. OFF	CUT. OFF	CUT. OFF	
59		CUT. OFF		CUT. OFF	CUT. OFF	CUT. OFF	
60	CUT. OFF	CUT. OFF		CUT. OFF	CUT. OFF	CUT. OFF	

Table 1-3 PCB1 Timing and Trigger Address Jumper Positions

			Jumpers, Dipswitch		
Monitor Address	JP8, S2-1	JP9, S2-2	JP10, S2-3	JP11, S2-4	JP12, S1-1
1					
2	CUT, OFF				
3		CUT, OFF			
4	CUT, OFF	CUT, OFF			
5			CUT, OFF		
6	CUT, OFF		CUT, OFF		
7		CUT, OFF	CUT, OFF		
8	CUT, OFF	CUT, OFF	CUT, OFF		
9				CUT, OFF	
10	CUT, OFF			CUT, OFF	
11		CUT, OFF		CUT, OFF	
12	CUT, OFF	CUT, OFF		CUT, OFF	
13			CUT, OFF	CUT, OFF	
14	CUT, OFF		CUT, OFF	CUT, OFF	
15		CUT, OFF	CUT, OFF	CUT, OFF	
16	CUT, OFF	CUT, OFF	CUT, OFF	CUT, OFF	
17					CUT, OFF
18	CUT, OFF				CUT, OFF
19		CUT, OFF			CUT, OFF
20	CUT, OFF	CUT, OFF			CUT, OFF
21			CUT, OFF		CUT, OFF
22	CUT, OFF		CUT, OFF		CUT, OFF
23		CUT, OFF	CUT, OFF		CUT, OFF
24	CUT, OFF	CUT, OFF	CUT, OFF		CUT, OFF
25				CUT, OFF	CUT, OFF
26	CUT, OFF			CUT, OFF	CUT, OFF
27		CUT, OFF		CUT, OFF	CUT, OFF
28	CUT, OFF	CUT, OFF		CUT, OFF	CUT, OFF

Section 2 — Outline, Mounting, and Installation

The information in this section describes a typical installation only.

NOTE

This section may not contain all installation information that may apply to your airport. Consult installation drawings prepared specifically for your airport and those supplied with the equipment. Site installation drawings take precedence over drawings in this manual.

ATTENTION

Each carton contains one light. The position at which the light is to be installed is marked on the carton and on an ID label on the outside of the power converter.

Unpacking

Inspect shipping cartons immediately for signs of damage. Damage claims should be reported promptly to the freight handler. Check package contents against the packing list and inspect each item for visible damage.

Tools

No special tools are necessary. The following hand tools are suggested for installation and maintenance:

- #2 Phillips-head screwdriver
- 9- or 12-inch (# 2 - $\frac{3}{16}$ "), flat-blade screwdriver
- 9- or 12-inch (# 3 - $\frac{5}{16}$ "), flat-blade screwdriver
- Medium, slip joint pliers
- 8-in. adjustable wrench
- Long-nose pliers
- Set of combination wrenches
- Assorted nut-drivers or sockets ($\frac{1}{4}$ ", $\frac{5}{16}$ ", $\frac{3}{8}$ ", $\frac{7}{16}$ ")
- Universal terminal crimping tool
- Spanner wrench for 2-inch conduit locking nut
- Triplet™ Model 630-NA or equivalent analog voltmeter, or a digital meter with an averaging function

Access

Screws in a bezel ring retain the flashtube in the flashhead.

Wing-handle fasteners attach the power converter cover to its base plate.

System Configurations

The main configuration for ElectroFlash FTS 800A systems is:

- A number of approach lights (ALS), also referred to as Runway Alignment Indicator Lights or RAIL lights. Each light consists of a flashhead and a power converter.
- An FTC 183 System Controller.

Each system configuration uses one FTC 183 Controller. See *Figure 2-2* for more information.

The factory numbers Lighting Units to indicate their position. A label on the outside of the power converter identifies each light. This is particularly important in a system of sequentially flashing lights. The sequential lights are labeled numerically in the order of the flashing sequence. Light Number 1 is installed farthest from the runway threshold, and the highest numbered light is closest to the runway threshold.

Mounting

Each lighting unit consists of a power converter and a flash head. They may be mounted together as a single unit. *Figure 2-3* shows a comounted assembly. Frangible couplings suitable for a comounted assembly are available from FTCA.

Mount separately mounted flashheads according to the requirements of individual installations. The bracket on the flashhead has a 2" NPT threaded hole for mounting on a pipe support.

Wiring

Figure 2-2 provides wiring guidelines for the Lighting Units in the system. This figure is for reference only and may not exactly agree with details in your installation. Always follow instructions in the Installation Wiring Diagram supplied with your equipment.

CAUTION

This equipment is power phase sensitive. L1 and L2 must be wired to F1 and F2 in a consistent manner throughout the entire lighting system.

Note that the wiring diagrams define minimum requirements and may not comply with all applicable electrical codes. It is your responsibility to comply with all prevailing electrical codes.

Use the following wiring guidelines:

- FTCA recommends 600V insulation on all wires that interconnect the system.
- Determine the wire gauge by considering service voltage, length of the wire run, and total load (number of lighting units). Use a value of 200 VA per Lighting Unit and do not permit the voltage drop caused by wire resistance to exceed 5% at any light. The FTC 183 Controller adds 25 watts to the total load.
- Use the value of 200 volt-amperes to determine the circuit breaker or the slow-acting fuse rating at the service disconnect box.
- Wire the primary power of the system through an external circuit breaker and power switch (see *Figure 2-1*).
- Control and monitor wires from the controller connect to the lighting units. Wire control lines to all Lighting Units in the system by using two #14 AWG (minimum) conductors *twisted together at 6 turns per foot*.
- FTCA recommends a counterpoise consisting of solid copper.
- FTCA does not recommend grounding to the counterpoise for lightning protection.
- Ground all cases to a grounding rod. FTCA provides a grounding lug on each power converter base.

For more information, see *Figure 2-2*.

Installation Checklist

Complete the following steps before applying power:

1. Equipment Damage:

Inspect all equipment for damage.

2. Required Equipment:

Verify the received equipment against the packing list to ensure completeness.

3. Power Converter Mounting:

- Position and mount each unit allowing adequate clearance for opening the covers.
- Check hardware inside the case to ensure that the chassis mounting screws and nuts are tight.
- Mount the power converter away from radio frequency interference (RFI).

4. Power Converter Installation:

Examine the installation drawings and use the following guidelines:

- Check for proper incoming service power.
- Wire each unit according to the instructions.
- Ground the power converter to a grounding rod.
- Check all electrical connections for tightness.
- Check all terminal strip connections for tightness.

5. Flashhead Installation:

- Check the wiring of the flashhead cable to the flashhead.
- Check the aim of the flashhead.

After completing all the steps listed above, turn on the power and perform an operational checkout from procedures in Section 3 of this manual.




Figure 2-1 Recommended External Power Switching

24




Figure 2-2 Installation Wiring of an FTS 800A System with Four Lighting Units





Figure 2-3 Comounted Lighting Unit — Mounting and Outline



26

Figure 2-4 Flashhead Mounting and Outline





Figure 2-5 Flashhead Internal Wiring

72



3-7403-04 REV L

3740304LIW

Figure 2-6 Power Converter Internal Wiring

Section 3 — Maintenance and Troubleshooting

Preventive Maintenance

Carry out the following inspection and cleaning procedures at least once a year:

1. Verify that moisture has not accidentally entered the equipment through gaskets or seals, or collected inside as condensation.
2. Verify that all drain holes are clear.
3. Check terminal blocks and relays for evidence of corrosion and electrical arcing. Clean or replace any component that shows evidence of high-voltage damage.
4. Check flashtube connections for signs of pitting or arcing. Verify that anode and cathode connections are firmly tightened.
5. Check all electrical connections for tightness and verify the absence of corrosion or electrical arcing.

Storage

No special considerations are required for long-term storage of any major assembly, such as the power converter or flash head, or any internal component. Circuit boards, when not installed in the equipment, should be kept in antistatic bags or containers.

RFI Problems

Presence of radio frequency interference (RFI) can cause a light to flash intermittently, at the wrong rate, or at the wrong intensity. RFI can enter the light by way of *any* wire to or from the unit. For example:

- RFI on primary power wires could cause errors in flash rate and intensity.
- RFI on the control wire could cause a light to stay at night intensity.
- Strong RFI could burn out PCB1 components.

While FTCA designed circuits to reject or bypass RFI, complete immunity cannot be guaranteed beforehand. It may be necessary after installation to add external filters

or use other methods to reduce RFI entering the equipment.

Operation Checkout

Use the controller and the following procedure:

- Ensure that power is applied to the entire system.
- Turn the intensity switch on the controller to **L**. The lights should all flash sequentially at *low* intensity.
- Turn the intensity switch to **FLASH INHIBIT**. The lights should not flash.
- Turn the intensity switch on the controller to **M**. The lights should all flash sequentially at *medium* intensity.
- Turn the intensity switch on the controller to **H**. The lights should all flash sequentially at *high* intensity.
- At each preceding position, check the **LIGHT POSITION** confirmation lights on the front panel of the controller. They should all be *green* for each light position flashing correctly. A *red* position indicates a failing light.
- Observe the lights visually. The entire system should flash sequentially.
- If any light is failing, see *Troubleshooting*.

Mode Control for Manual Operation

The following steps in *Table 3-1 Mode Control* explain how to force a single Light to operate continuously at a fixed flash intensity (mode), information that is useful for troubleshooting the Light to check its operation at all three flash intensities.

Table 3-1 Mode Control

Intensity	Jumper Placement ¹
HIGH	Between Test Point 1 (TP1) labeled TEST and TP5 labelled DAY.
MEDIUM	Between Test Point 1 (TP1) labeled TEST and TP4 labelled TWI.

Table 3-1 Mode Control

Intensity	Jumper Placement ¹
LOW	Between Test Point 1 (TP1) labeled TEST and TP3 labelled NITE.
LTV	<i>Factory use only.</i> Causes continuous triggering. Do not use.

1. Be certain to remove all jumpers after checking the Light.

Troubleshooting

For effective troubleshooting, accurately observe the system's operating behavior. This can often lead you directly to the cause of a problem. The diagnostic procedures in this subsection are divided into the two following categories:

- System-level malfunctions, where all lighting units exhibit the same abnormal behavior
- Symptoms applying to one or more individual lighting units, but not to all of them

The most effective troubleshooting procedure begins with observing the behavior of the Lighting Unit. This often leads directly to a faulty component or other abnormal condition. *Table 3-2* lists many of the symptoms that a malfunctioning Lighting Unit might exhibit. In *Table 3-3* these symptoms are correlated with components, assemblies, or conditions that, if defective or abnormal, could cause the Lighting Unit to behave as observed.

For example, assuming that the Lighting Unit does not flash at all but some of its circuits are still operating; that is, fuses are not blown, relays operate, and so forth. This behavior is symptom C in *Table 3-2*. *Table 3-3* indicates that a defective timing and trigger board would most likely cause symptom C behavior. The next most likely cause would be a defective rectifier board. The third would be the LOW mode capacitor, and so forth. Each item in *Table 3-3* is listed in the order of its likelihood of causing the failure.

Most components suspected of causing a problem can be checked by following the procedures in *Section Component Testing*.

Table 3-2 Observed Behavior

OBSERVED BEHAVIOR			
Symptom Code	Flash Observation		Comments
	High/Med Intensity	Low Intensity	
A	NO	NO	All circuits are dead
B	NO	NO	Repeatedly blows line fuses
C	NO	NO	Some circuits are functioning
D	No flash	No flash	No flash
E	OK	OK	Out of sequence
F	Weak	OK	Sometimes skips a flash
G	OK	OK	Erroneous fail

Table 3-3 Defective Component Locator Code from Table 3-2

Item No.	Component	Codes						
		A	B	C	D	E	F	G
C1	Main Capacitor Bank			4				
C2	LOW Mode Capacitor			3	4			
C3	Tuning Capacitor						1	

Table 3-3 Defective Component Locator Code from Table 3-2

Item No.	Component	Codes						
		A	B	C	D	E	F	G
F1, F2	Fuse	1						
FT101	Flashtube			6			2	
K2	Mode Relay							
PCB1	Timing and Trigger Board			1 and Footnote 3		Footnote 1		2
PCB2	HV Rectifier Board			2	1			
S1	Interlock Switch	2						
T1	Power Transformer	3	2	5				
T2	Sense Transformer							1
T101	Trigger Transformer			7				
VR1	Suppressor Assembly		1					
-	Open Control Line				1			
Footnote 2						3		
Footnote 3			3					

1. Boards not installed in the assigned locations for the correct sequence.
2. Check for RFI (see *Section RFI Problems*).
3. Check for a short circuit in the 24 VAC or 120 VAC secondary windings of the power transformer.

Component Testing

Always make resistance measurements with the power turned off. Voltage measurements require power to be on; however, perform all preliminary steps such as connecting test leads or circuit jumpers, or disconnecting existing circuit connections, with the power turned off and storage capacitors discharged.

PERSONNEL HAZARD WARNING

NOTE

Read the Warning on page iii.
Never depend on interlocks alone to remove unsafe voltages. Always check circuits with a voltmeter. Under no circumstances remove or alter any safety interlock

Inspection

Closely inspect the units and check the connections against the installation instructions. Also, a close inspection may reveal insulation breakdown, an overheated

component, corrosion, loose connections, faulty relays, incorrect hookup, and so forth.

Wires or cables that move repeatedly will ultimately break. Ensure that all cables (the flash head cable in particular) are securely fastened at short intervals to the structure or other supports.

Power Converter

Capacitors (C1, C2, C3)

Test capacitors with an ohmmeter capable of measuring one megohm or greater, using the procedure described following.

Resistance measured between the terminals of a fully discharged capacitor is initially zero and increases steadily with time if you leave the ohmmeter leads across the terminals. Eventually, an open circuit condition occurs. The time it takes for the complete transition from zero to maximum depends on the total amount of capacitance. A capacitor disconnected from other circuitry is defective if it does not exhibit this behavior. Manually discharge the capacitor before repeating this measurement. This procedure may not detect a failure that occurs at high voltage only. Please note that the final measured resistance across

C1 is limited to 100K ohms unless you disconnect the safety bleed resistor R1.

Relays (K1, K2)

A malfunctioning relay may have faulty contacts, a sticky mechanism, or a defective coil. You may determine the first two possibilities by inspection and by manually exercising the armature. Perform the following resistance measurement to confirm a defective coil:

1. Remove the PCB1.
2. Measure coil resistance between TB3-7 and the chassis to test Low Mode Relay K2.
3. Measure coil resistance between TB3-8 and the chassis to test High Mode Relay K1.

The measured coil resistance in either case should be approximately 290 ohms.

High Voltage Rectifier Board (PCB2)

Replace PCB2 with one known to be in good condition.

High Voltage Transformer (T1)

To test this transformer, first remove PCB1 and PCB2. Apply power to the unit and measure secondary winding voltages at the terminals indicated.

Table 3-4 T1 Transformer Voltages

Terminals	Voltage Range
TB4-3 to TB4-11	900-1050 VAC*
TB3-9 to chassis	100-120 VAC
TB3-2 to TB3-3	22-26 VAC

* If this AC voltage is substantially below the specified minimum value, check tuning capacitor C4.

Trigger Coupling Transformer (T3)

Visually observe the transformer for damage. Check the transformer for open windings by measuring the primary and secondary windings with an ohmmeter. An open

winding indicates infinite ohms on the ohmmeter. A normal winding should indicate zero ohms.

Timing and Trigger Board (PCB1)

Replace this circuit board with one known to be in good condition.

Cut the jumpers or set the dipswitches on the replacement board to match exactly those on the original board. Refer to *Tables 1-2* and *1-3*.

Bleed Resistor (R1)

The measured resistance of this component should be 100,000 ohms.

Interlock Switch (S1)

Try adjusting the switch bracket. The switch should clearly read zero ohms when it is closed and infinite ohms when it is open.

Flashhead

Flashtube (FT101)

Visually inspect the flash tube for broken electrodes, cracked glass, and the solder connections of the pins. A darkened envelope does not necessarily mean the light output would be unacceptable. Before concluding that a faulty flash tube is responsible for an inadequate flash, first rule out other possible causes such as weak or absent discharge voltage or triggering pulses.

Component Removal and Replacement

This section contains instructions for removal and replacement of most major replaceable components. *Section 4* provides component location diagrams for assembly and disassembly. Section 2 provides an internal wiring diagram of the FH 800 Flashhead and the PC 800 Power Converter.

High Voltage Transformer (T1)

Removal

1. Disconnect wires leading to the transformer
2. Remove four screws holding the transformer to the rear of the chassis and remove the transformer from the chassis.

Replacement

Reverse the Removal procedure.

Trigger Coupling Transformer (T3)

Removal

1. Disconnect the wires to quick-connects QC1 and QC4. Note the orientation of the wires (top wire of the primary or secondary coil).
2. Remove the two 4-40 x 2" Phillips-head screws holding the transformer assembly to the bracket.
3. Remove the transformer.

Replacement

1. Reinstall the transformer assembly to the bracket using the two long screws. Ensure that the wires have the same orientation on the core.
2. Reattach the electrical wires. Verify that wiring is correct.

Timing and Trigger Board (PCB1)

Removal

1. Loosen, but do not remove, all eleven screws holding the circuit board to TB3.
2. Loosen, but do not remove, the screws at the top that hold the board to the front of the chassis and lift the board from TB3.

Replacement

1. Cut the flash jumpers or set the dipswitches on the replacement board to match those in the board being replaced. Refer to *Tables 1-2* and *1-3*.
2. Cut the confirmation jumpers or set the dipswitches in the replacement board to match those in the board being replaced.
3. Reverse the Removal procedure.

HV Rectifier Board (PCB2)

Removal

1. Loosen, but do not remove, all eleven screws holding the circuit board to TB4.
2. Loosen, but do not remove, the screws at the top that hold the board to the front of the chassis and lift the board from TB4.

Replacement

Reverse the Removal procedure.

Energy Storage Capacitors

Removal

1. Disconnect the wires leading to the capacitors.
2. Remove the hold-down screws. Lift capacitors from their receiving holes and away from the chassis.

Replacement

Insert capacitors into their respective receiving holes. Replace hold-down screws to secure capacitors to the chassis. Reconnect wires to capacitors and verify that wiring agrees with the internal wiring diagram in Section 2. Wires must be replaced exactly as removed. In some instances, a quick-connect wire terminal does not seat properly if it is not placed on the terminal cluster exactly as it was before removal. Sometimes the insulation on the wire terminal interferes with the insulation surrounding the terminal cluster on the capacitor.

This page is intentionally left blank.

Section 4 — Replaceable and Spare Parts

Customer Service

Technical Assistance (800) 821-5825
Telephone: (615) 261-2000
Facsimile: (615) 261-2600
Shipping Address:
Flash Technology Corporation of America
332 Nichol Mill Lane
Franklin, TN 37067

Ordering Parts

To order spare or replacement parts, call FTCA customer service at 1-800-821-5825.

Power Converter Parts and Spare Parts

Table 4-1 lists the major replaceable parts for the power converter and spare parts for emergency repairs.

Flashhead Parts

Table 4-2 lists the major replaceable parts for the flashhead.

Returning Equipment

To return equipment to FTCA, call Customer Service for a Return Material Authorization (RMA) number.

Repackaging

Equipment must be returned in a container that provides maximum protection during shipping and handling. If the original cartons and packaging material are no longer available, package the lighting unit as follows:


Power Converter: Ship and package the power converter in an upright position; that is, with the base downward. Pad the power converter so that corners cannot penetrate the box during shipment. Box each power converter separately using a double thickness cardboard container and adequate padding. Do not drop. Use appropriate warning labels on the outside of the container.

Flashhead: If you send the flashhead separately, package it in any strong, corrugated cardboard box with enough firm padding surrounding the flashhead to prevent damage.

Table 4-1 Power Converter Major Replaceable Parts

Description	Part Number	Quantity
Capacitor, Tuning, C4, 3 mfd.	6577903	1
Capacitor, Low Intensity, C1, 20 mfd.	6731401	1
Capacitor, High Intensity, C2, 70 mfd.	6720401	1
Capacitor, High Intensity, C5 & C6, 15 mfd.	6731301	1
Capacitor, Medium Intensity, C7, 5 mfd.	6731101	1
Choke, Flash, L2	4175200	1
Timing and Trigger Board, PCB1	2498815	1*
Enclosure	3727900	1
Fuse, Power (F1, F2)	4900303	2
HV Rectifier Board, PCB2	2458002	1*
Interlock Switch, S1	4901220	1
Resistor, R1	6900541	1
Resistor, R2	6900542	1
Resistor, Buffer, R3	8435211	1
Resistor, R4	8435212	1
Relay, Mode (K1, K2)	8900494	2*
Sense Module, PCB3	2811101	1
Suppressor, VR1	6901081	1
Suppressor, VR2	6901079	1
Transformer, Power, T1, 60 Hz, 120 VAC	8841201	1
Transformer, Power, T1, 60 Hz, 240 VAC	8841202	1
Transformer, Power, T1, 50 Hz	8842901	
Transformer, Trigger Coupling, T3	8336710	1
Terminal Strip, 6-position, TB1	8721006	1
Terminal Strip, 8-position, TB2	8721008	1
Terminal Strip, 11-position, TB3, TB4	8721011	2

* Recommended as a spare part.



3740304FCL

Figure 4-1 Power Converter Component Locations

Table 4-2 Flashhead Replaceable Parts

Description	Part Number	Quantity
Trigger Transformer	8288201	1
Flashtube FT 101	8901701	1*
RC Network RC 101	1403411	1
Post, Ceramic	5900842	6
Retaining Bezel	3735202	1

* Recommended as a spare part.




Figure 4-2 Flashhead Component Locations

INDEX

A

Access 2-1

C

Capacitor
testing 3-3

Checkout
operational 3-1

Component
locations 4-3
flashhead 4-4
system
overview 1-1

Component locations
flashhead 4-4
power converter 4-3

Component removals 3-4

Component testing 3-3
flashtube 3-4
power converter 3-3

Configuration
system 2-1

Confirmation
flash
jumper 1-2

Controller function 1-2

Customer service 4-1

E

Equipment
returning 4-1

F

Flash confirmation
jumper 1-2

Flashhead
component locations 4-4
installation check 2-3
internal wiring 2-7
mounting and outline 2-6
overview 1-1

Flashhead component locations 4-4

Flashtube
component testing 3-4

I

Indicator lamps 1-3

Inspection 3-3

Installation
checklist 2-2
flashhead check 2-3

power converter check 2-2
tools needed 2-1
wiring diagram 2-4

Installation wiring
system 2-4

Intensity
lighting unit 1-2
mode control
on board jumpers 3-1

Internal wiring
flashhead 2-7

Introduction
system 1-1

J

Jumper
flash confirmation 1-2

Jumpers 1-2
60/50 Hz Operation 1-2
light position 1-2
on board
mode control 3-1

L

Lamp
neon 1-3

Lamps 1-3

LED indicators 1-3

LEDs 1-3

Light
position
jumpers 1-2

Lighting unit
mounting and outline 2-5
position programming 1-2

Location
power converter components 4-3

Locations
flashhead components 4-4
power converter components 4-3

M

Maintenance
preventive 3-1

Mode control
intensity
single light 3-1

Mode control for manual operation 3-1

Monitor
line 1-2

Mounting 2-1

- power converter check 2-2
- system components 2-1
- Mounting and outline
 - comounted unit 2-5
 - flashhead 2-6

N

- Neon lamp 1-3

O

- Operation 1-2
 - checkout 3-1
 - lighting unit 1-2
 - manual 3-1
 - overview 1-2
- Options 1-1
- Ordering parts 4-1

P

- Part lists 4-2
- Parts
 - ordering 4-1
 - replaceable 4-1
 - spare 4-1
- PCB1
 - board pictorial 1-4
 - testing 3-4
- PCB2
 - testing 3-4
- Position
 - lighting unit
 - programming 1-2
- Power converter 4-3
 - component locations 4-3
 - component testing 3-3
 - internal wiring 2-8
 - mounting check 2-2
- Power switching 2-3
 - recommended external 2-3
- Preventive maintenance 3-1
- Programming
 - light position 1-2
 - lighting unit position 1-2

R

- R1
 - testing 3-4
- Radio Frequency Interference 3-1
- Radio frequency interference 3-1
- Reference signal 1-2
- Relay
 - testing 3-4

- Removal 3-4
- Removals
 - component 3-4
- Repackaging 4-1
 - for shipment 4-1
- Replacement 3-4
- Returning equipment 4-1
- RFI 3-1

S

- S1
 - testing 3-4
- Service
 - customer 4-1
- Setup
 - for the light 1-2
- Shipment
 - repackaging 4-1
- Signal
 - reference 1-2
- Spare parts 4-1
- Specifications 1-1
- Storage 3-1
- Switch
 - main power 2-3
- System
 - component
 - mounting 2-1
 - overview 1-1
 - components 1-1
 - configuration 2-1
 - configurations 2-1
 - description of 1-1
 - installation 2-4
 - specifications 1-1
- System introduction 1-1

T

- T1
 - testing 3-4
- T3
 - testing 3-4
- Testing
 - capacitor 3-3
 - components 3-3
 - PCB1 3-4
 - PCB2 3-4
 - R1 3-4
 - relay 3-4
 - S1 3-4
 - T1 3-4

T3 3-4
TI transformer voltages 3-4
Tools
 installation & maintenance 2-1
Troubleshooting 3-2
 tables 3-2

U
Unpacking 2-1

V
Voltages
 T1 transformer 3-4

W
Wiring 2-2
 installation 2-4
 internal
 flashhead 2-7
 power converter 2-8

~~ End OF Document ~~